# Multiplexing Techniques

### **Session Objectives**

#### • Introduction

- Multiplexing
- Categories of multiplexing

#### • Frequency-division multiplexing (FDM)

- Multiplexing process
- De-multiplexing process
- Examples

#### • Wavelength division multiplexing (WDM)

#### • Time-division multiplexing (TDM)

- Synchronous TDM
- Time slots and frames
- Interleaving
- Empty slots
- Data rate management: multilevel, multiple-slot, and pulse stuffing

#### **MULTIPLEXING**

- Multiplexing is the set of techniques that allows simultaneous transmission of multiple signals across a single data link.
- As data and telecommunications use increases, so does traffic.
- We can accommodate this increase by continuing to add individual links each time a new channel as needed, or we can install higher-bandwidth links and use each to carry multiple signals.






Figure-1: Dividing a link into channels

### **Categories of Multiplexing**




#### **Frequency-Division Multiplexing**


- Frequency-division multiplexing (FDM) is an analog technique that can be applied when the bandwidth of a link (in hertz) is greater than the combined bandwidths of the signals to be transmitted.
- In FDM, signals generated by each sending device modulate different carrier frequencies.
- These modulated signals are then combined into a single composite signal that can be transported by the link.



### **Multiplexing Process**



### **De-multiplexing Process**




### Example 1

Assume that a voice channel occupies a bandwidth of 4 kHz. We need to combine three voice channels into a link with a bandwidth of 12 kHz, from 20 to 32 kHz. *Show the configuration, using the frequency domain*. Assume there are *no guard bands*.

#### **Solution**

Shift (modulate) each of the three voice channels to a different bandwidth, as shown in below.




### Example 2

Five channels, each with a 100-kHz bandwidth, are to be multiplexed together. What is the minimum bandwidth of the link if there is a need for a guard band of 10 kHz between the channels to prevent interference?


#### **Solution**

For five channels, we need at least four guard bands. This means that the required bandwidth is at least  $5 \times 100 + 4 \times 10 = 540$  kHz, as shown in *Figure*.



#### Wavelength-Division Multiplexing

- Wavelength-division multiplexing (WDM) is designed to use the high-data-rate capability of fiber-optic cable.
- The optical fiber data rate is higher than the data rate of metallic transmission cable, but using a fiber-optic cable for a single line wastes the available bandwidth.
- Multiplexing allows us to combine several lines into one.




Wavelength-division multiplexing

Prisms in wave-length division multiplexing


#### **Time-Division Multiplexing**


- Time-division multiplexing (TDM) is a digital process that allows several connections to share the high bandwidth of a link.
- Instead of sharing a portion of the bandwidth as in FDM, time is shared.
- Each connection occupies a portion of time in the link.



- Note that the same link is used as in FDM; here, however, the link is shown sectioned by time rather than by frequency.
- In the figure, portions of signals 1, 2, 3, and 4 occupy the link sequentially.

### Synchronous Time-Division Multiplexing: Time slots and frames





Each frame is 3 time slots. Each time slot duration is T/3 s.

In Synchronous TDM, the data rate of the link is n times faster, and unit duration is n time shorter

#### Example 3


In *above figure*, the data rate for each input connection is 1 kbps. If 1 bit at a time is multiplexed (a unit is 1 bit), what is the duration of

- 1. each input slot,
- 2. each output slot, and
- 3. each frame?

#### **Solution**


- 1. The data rate of each input connection is 1 kbps. This means that the **bit duration** is 1/1000 s or 1 ms. The duration of the input time slot is 1 ms (same as bit duration).
- 2. The duration of each output time slot is one-third of the input time slot. This means that the duration of the output time slot is 1/3 ms.
- 3. Each frame carries three output time slots. So the duration of a frame is  $3 \times (1/3)$  ms, or 1 ms. The duration of a frame is the same as the duration of an input unit.

#### **INTERLEAVING**



### Example 4


Four channels are multiplexed using TDM. If each channel sends 100 bytes/s and we multiplex 1 byte per channel, show the frame traveling on the link, the size of the frame, the duration of a frame, the frame rate, and the bit rate for the link.




#### **Solution**

- •The multiplexer is shown in *Figure*. Each frame carries 1 byte from each channel; the size of each frame, therefore, is 4 bytes, or 32 bits.
- •The frame rate is 100 frames per second. [100 \* 8=800 bits/s; 800 \* 4 =3200 bits/s; 3200/32=100 frame/sec]
- •The duration of a frame is therefore 1/100 s.
- •The link is carrying 100 frames per second, and since each frame contains 32 bits, the bit rate is  $100 \times 32$ , or 3200 bps.


## **Empty Slots**




### **Multilevel Multiplexing**



### Multiple-slot Multiplexing



### **Pulse stuffing**



#### **Summary**

In this section we have discussed the following:

- ✓ Multiplexing concept
- ✓ Multiplexing techniques as TDM, FDM and WDM.
- ✓ Interleaving and bit stuffing

hank nou!